


QUICK GUIDE doblePRIME *IDD*TM

Intelligent Diagnostic Device



DOBLE ENGINEERING COMPANY



This Manual is solely the property of the Doble Engineering Company (Doble) and is provided for the exclusive use of Doble Clients under contractual agreement for Doble Test equipment and services.

In no event does the Doble Engineering Company assume the liability for any technical or editorial errors of commission or omission; nor is Doble liable for direct, indirect, incidental, or consequential damages arising out of or the inability to use this Manual.

Government Restricted Rights Legend: Use, Duplication, or Disclosure by the U.S. Government is subject to restrictions as set forth in subparagraphs (c)(1) and (c)(2) of the Commercial Computer Software - Restricted Rights Clause at FAR 52.227-19.

This manual is protected by copyright, all rights reserved. No part of this book shall be reproduced, stored in a retrieval system, or transmitted by any means, electronic, mechanical, photocopying, recording, or otherwise without written permission from the Doble Engineering Company.

Doble and the Doble logo are trademarks of Doble Engineering Company.

Microsoft, Windows, Windows 95, Windows 98, Windows 2000, Windows NT, XP, Vista, Windows 8, and Windows 10 are registered trademarks of Microsoft Corporation in the United States and/or other countries.

©1999-2017 Doble Engineering Company

All Rights Reserved

IDD™


product outline:

The doblePRIME IDD™ Bushing Monitor detects deterioration in bushings, finding abnormalities in the insulation and issuing actionable alerts.

The doblePRIME IDD Bushing Monitor provides leakage current and phase analysis for up to 12 bushings, measuring parameters for each bushing individually and together.

This intelligent device uses its embedded Expert System to provide you with notifications and alarms based on comparisons between off-line and calculated on-line data. Designed to fit your monitoring program, the doblePRIME IDD Bushing Monitor can operate as a standalone device or as part of a doblePRIME Condition Monitoring Platform.

Over almost 20 years of successful monitoring Doble has identified two distinct failure modes – rapid onset and graceful decay – and have documented cases of averting bushing failures in both modes.



- Capture bushing current waveforms in real time
- Calculates values for power factor and capacitance
- Records data at user specified intervals, or ad hoc
- Displays alerts locally and remotely
- Intelligent Expert System learns what is normal for your bushings
- Notifications based on latest analysis techniques – and built on Doble's decades of experience in the field


Installation options:

The doblePRIME IDD is provided in an anodized aluminum housing, compatible with other doblePRIME modules for ease of installation.

Panel Mount hole locations


The installation options are:

- Panel Mount: using brackets provided.
- DIN Rail Mounting: DIN Rail bracket is available as part of the 030-2176-01 Kit
- Free Standing: Rubber feet can be supplied as part of the 030-2176-01 Kit



Identify Connections

Help with identifying the connections found on the IDD Intelligent Diagnostic Device.



IDD Version: 100 ●

Connection Details:

1. Power supply: 24VDC 1A
2. Optional Ethernet interface for IEC-61850 (available Q4 2017)
3. Relay output: 4 x relay, 250VAC 5A, switched according to alert conditions detected by IDD a. ACTION (NC); b. WARNING (NC); c. INFO (NC); d. STATUS (NO)
4. LAN 1: Ethernet switch, access to doblePRIME user interface (http) and communication protocols (Modbus TCP, DNP3)
5. Analogue input: 4 x 4-20mA, for general purpose measurements of analogue values, e.g. DGA, temperature, pressure, etc.
6. Digital input: sink or source, for general purpose measurement of switch state, e.g. pumps, fans, etc.
7. Timing input: 1pps fibre, from optional Doble GPS timing source
8. Timing input: IRIG-B BNC connector, from existing station timing system
9. RS485: 2-wire, Modbus Master/Slave or DNP3 Master/Outstation, for communication with supervisory systems or monitoring devices
10. USB interface, options: a. WiFi access point; b. Firmware update; c. Data display
11. Indicator LED: switched according to alert conditions detected by IDD a. ACTION (flashing red); b. WARNING (flashing yellow); c. INFO (flashing green); d. STATUS (flashing blue)
12. Bushing Set 1: 3 x bushing leakage current measurement
13. Bushing Set 2: 3 x bushing leakage current measurement
14. Bushing Set 3: 3 x bushing leakage current measurement
15. Bushing Set 4: 3 x bushing leakage current measurement

Quick Connection Reference:


| | doblePRIME Instrument | | | | | |
|-----------------|-----------------------|-----|-----|--|--|--|
| | 100 | 101 | 102 | | | |
| Bushing Inputs | 12 | 6 | 6 | | | |
| Voltage Inputs | ✗ | 3 | ✗ | | | |
| 4-20mA Inputs | 4 | 4 | ✗ | | | |
| Digital Inputs | 4 | 4 | ✗ | | | |
| Alert Relay | 4 | 4 | 4 | | | |
| Alert LED | 4 | 4 | 4 | | | |
| GPS Timing* | ✓ | ✓ | ✗ | | | |
| Ethernet Switch | ✓ | ✓ | ✓ | | | |
| USB 2.0 | ✓ | ✓ | ✓ | | | |
| RS485 | 2 | 2 | 1 | | | |

* Additional equipment might be required

IDD Version: 101 ●



IDD Version: 102 ●




Default IP Configuration

Section A: Login Details

You must have this information to log in:

- dblePRIME IP address - [192.168.1.234](#)
- Username - [ad](#)
- Password - [idd2ad](#)

If you need any of this information, consult your system administrator.



Section B: Login Procedure

To log in to dblePRIME:

1. When the front panel of the IDD show blue and green LEDs (see page 4: 11. Indicator LED) the device has finished booting, this normally takes approximately 1 minute, the IDD will now require an additional 30 seconds to start communicating.
2. Connect your computer to the IDD using an ethernet cable.
3. Set your computer IP address and subnet to match the IDD (see image; left)
4. Open a browser and enter the IP address.
5. Enter your username and password.
6. (Optional) If this is the first time you have logged in, Doble recommends that you change your password immediately.
Do not continue to use the password provided by Doble.
7. Click [Sign In](#).



Section C: Reset Procedure

Details of the procedure:

1. Perform the IP reset on the IDD by inserting and holding a paperclip or similar in the pinhole (see pinhole location on page 4: Identify Connections); the LEDs will go out then light up in sequence bottom to top, when all the LEDs start flashing at the same time you can release the paperclip from the pinhole.
2. After the paperclip is removed out of the pinhole the IDD will perform a reset itself.
3. Go to section B to continue.

Troubleshooting Indicators

A normal state is indicated by the green and blue indicator LEDs being lit.



OPERATION:

BLUE - indicates system active

STEADY GREEN - indicates Normal (healthy) state.

FLASHING GREEN - indicates transition to INFO. INFO provides information

FLASHING YELLOW - indicates WARNING. Requires further investigation.




FLASHING RED - indicates ACTION. Requires immediate attention!

RELAY:

OPERATION in NORMAL condition:


INFO/WARNING/ACTION - Normally OPEN

STATUS - Normally Closed



NOTES

NOTES



Doble Engineering Company Worldwide Headquarters
85 Walnut Street
Watertown, MA 02472 USA
tel +1 617 926 4900
fax +1 617 926 0528



EXPERIENCE.
KNOWLEDGE.
INSIGHT.

SOLUTIONS BUILT ON A CENTURY
OF INNOVATION AND EXPERTISE.